

## SOP for Updating FW V1.00\_1036 for EK-350U


### Procedure

1. Check the original FW version of the projector
2. Install USB driver to PC  
(once required for each PC)
3. Updating FW V1.00\_1036 to projector
4. Initializing the projector

## **1. Check the original FW version of the projector**

### **Main FW Version check**


1. Please wait to Power LED in steady light Green
2. Press [Menu]+[Right] simultaneously more than 5 Seconds to Show Service menu For FW Version.



3. If shown as above picture, Main FW Version is [V1.00\_1032]  
Please write it down in your notes.

**Sub CPU FW Version check**

4. Press [Menu] to select "No." and Press [Up] or [Down] to select No. "102".  
Check Data (In below picture, it is "+1")
5. Press [Menu] to select "No." and Press [Up] or [Down] to select No. "103".  
Check Data (In below picture, it is "+5")
5. Sub-CPU FW Version is "102"+"103".  
If shown as below picture, it is [V1.05]




End.

## **2. Install USB driver to PC**


### **Windows 7 x64**

1. Reboot PC
2. Keep pressing F8 to get in the Advanced Boot Option page
3. Select the “Advanced Boot Options” to choose “Disable Driver Signature Enforcement”.




## Windows 10 X64


1. Select [Settings] and [Update&security]




2. Click [Restart now] from Recovery



3. Click [Troubleshoot]



4. Click [Advanced Options]




5. Click [Startup Settings]



6. Click [Restart]



7. Press [F7] to choice “Disable driver signature enforcement”



□ Setup projector in F/W downloading mode

1. Press [Power] + [UP] simultaneously



Image is different from EK-350U

2. Plug-in power code



Image is different from EK-350U

3. Keep press [power + up] button until warning LED in steady light and power LED in flashing light. (For EK-350U, until power LED is flashing light or steady light)



Image is different from EK-350U

4. Connect a USB Type A – B cable to desktop/laptop (For EK-350U, USB-A micro USB cable)




Image is different from EK-350U


## 5. Open [Device Manager]

Depending on the OS setting, there may be difference in view or how to start.


### Windows 10




### Windows 7



6. Update Driver Software from right click of mouse




7. Select [Browse my computer for driver software]



8. Browse for driver software on your computer


Please select the path: "...¥Windows\_Driver\_64bit" that we have provided.

Click [Next]




9. It should popup warning messages.

Click "Install this driver software anyway"



10. Install successfully.



This driver installation only needs to do once for each desktop/laptop

### **3. Updating FW V1.00 1036 to projector**

- Setup projector in F/W downloading mode

(If you continue from “2. Install USB driver to PC”, you can pass the steps 1 through 4.)

1. Press [Power] + [UP] simultaneously



Image is different  
from EK-350U

2. Plug-in power code



Image is different  
from EK-350U

3. Keep press [power + up] button until warning LED in steady light and power LED in flashing light. (For EK-350U, until power LED is flashing light or steady light)



Image is different  
from EK-350U


4. Connect USB Type A – B cable to desktop/laptop (For EK-350U, USB-A – micro USB cable)




Image is different  
from EK-350U

□ Start updating F/W



5. Launch FlashUpgrader(pw868\_use) from folder



6. Select “topaz\_all.inf” and “USB2.0”, and then press Flash



7. It will start to upgrade and just wait a few minutes



8. Press “Close” button to finish the process when updating is completed.

9. Unplug USB cable

10. Done.

## **4. Initializing the projector**

1. Turn on Projector
2. Press [Power] + [Down] simultaneously




Image is different from EK-350U

3. Keep press [power + down] button until Warning/Power LED in steady light



Image is different from EK-350U

4. The screen will display “EEPROM Initialize done...”



5. Please wait to Power LED in steady light Green
6. Press [Menu]+[Down] simultaneously



Image is different from EK-350U

7. Press [Menu] to select "Group" and Press [Up] or [Down] to select Group "200". Press [Menu] to select "No." and Press [Up] or [Down] to select No. "0". Press [Menu] to select "Data" and Press [Up] or [Down] to select Data "+1" (For LOGO)

Service mode		EIKI
Input	HDMI1	
Image	Standard	
Group	No.	Data
200	0	+1
Ver.	1.00	EK-350U

8. Press [Menu] and [Up] and [Down] to select Group 200 No.60 Data to "+1". (For Language)

Input	HDMI	
Image	Standard	
Group	No.	Data
200	60	+1

9. Press [Power] once to close Service menu.
10. Press [Power] twice to Projector off.




Image is different  
from EK-350U

11. Please plug off the power cord and then plug in once.  
Then Press [Power] to power on & double check.

12. Press [Menu]+[Down] simultaneously



Image is different  
from EK-350U


13. Press [Menu] to select "Group" and Press [Up] or [Down] to select Group "200"  
Press [Menu] to select "NO". and Press [Up] to "51".

Please check the original FW version:

- (1) If the projector's original FW version is V1.00\_1020 ~ V1.00\_1032 :

Please set Group 200,NO51,Data → **select 0**

(Press [Menu] to select "Data" and Press [Up] or [Down] to "+0".)




Service mode		EIKI
Input	HDMI1	
Image	Standard	
Group	No.	Data
200	51	+0
Ver.	1.00	EK-350U

- (2) If the projector's original FW version is V1.00\_1035 :

Please set Group 200,NO51,Data → **select 1**

(Press [Menu] to select "Data" and Press [Up] or [Down] to "+1".)



Service mode		EIKI
Input	HDMI1	
Image	Standard	
Group	No.	Data
200	51	+1
Ver.	1.00	EK-350U

14. Press [Power] to exit.
15. Press [Power] twice to Projector off.
16. Please plug off the power cord and then plug in once.  
Then Press [Power] to power on & double check.

Done.