

REMOTE CONTROL Code for EIP-WX5000

2008/11/6

No.	Key Description	Binary														HEX					
		System Code					Data Code								Judgement of frame		System Code		Data Code		Judgement of frame
		C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15					
1	UNDO	1	0	1	1	0	1	0	0	1	1	0	1	0	1	0	0	D	5	9	1
2	Zoom Up	1	0	1	1	0	0	0	0	1	0	1	0	1	1	0	0	D	A	8	1
3	Focus (+)	1	0	1	1	0	0	1	1	0	0	1	1	1	1	0	0	D	E	6	1
4	Zoom Down	1	0	1	1	0	1	0	0	1	0	1	0	1	1	0	0	D	A	9	1
5	Enter	1	0	1	1	0	1	1	1	0	1	0	1	0	1	0	0	D	5	7	1
6	Lens Shift	1	0	1	1	0	0	0	1	1	0	0	0	1	1	0	0	D	8	C	1
7	Keystone	1	0	1	1	0	1	1	0	1	0	0	0	1	1	0	0	D	8	B	1
8	Menu	1	0	1	1	0	0	0	1	0	0	0	1	1	1	0	0	D	C	4	1
9	Focus (-)	1	0	1	1	0	1	1	1	0	0	1	1	1	1	0	0	D	E	7	1
10	Cursol Right	1	0	1	1	0	1	1	1	1	0	0	1	0	1	0	0	D	4	F	1
11	Cursol Down	1	0	1	1	0	1	0	1	1	1	0	0	1	1	0	0	D	9	D	1
12	Cursol Left	1	0	1	1	0	0	0	0	0	1	0	1	0	1	0	0	D	5	0	1
13	Cursol Up	1	0	1	1	0	0	0	1	1	1	0	0	1	1	0	0	D	9	C	1
14	Enlarge (+)	1	0	1	1	0	1	0	1	1	0	1	1	0	1	0	0	D	6	D	1
15	Vol (+)	1	0	1	1	0	0	0	1	0	1	0	0	0	1	0	0	D	1	4	1
16	Freeze	1	0	1	1	0	1	0	1	1	0	0	0	1	1	0	0	D	8	D	1
17	Enlarge (-)	1	0	1	1	0	1	0	1	1	0	1	0	1	1	0	0	D	A	D	1
18	Vol (-)	1	0	1	1	0	1	0	1	0	1	0	0	0	1	0	0	D	1	5	1
19	Break Timer	1	0	1	1	0	0	0	1	0	1	1	0	1	1	0	0	D	B	4	1
20	Mute	1	0	1	1	0	1	1	1	0	1	0	0	0	1	0	0	D	1	7	1
21	Auto Sync	1	0	1	1	0	0	1	0	1	1	1	1	1	1	0	0	D	F	A	1
22	Picture Mode	1	0	1	1	0	1	0	0	1	1	1	0	0	1	0	0	D	3	9	1
23	Resize	1	0	1	1	0	0	1	1	1	1	0	1	0	1	0	0	D	5	E	1
24	Input1	1	0	1	1	0	1	0	1	0	1	1	0	0	1	0	0	D	3	5	1
25	Input2	1	0	1	1	0	0	1	1	0	1	1	0	0	1	0	0	D	3	6	1
26	Input3	1	0	1	1	0	1	0	1	0	1	1	0	1	1	0	0	D	B	5	1
27	Input4	1	0	1	1	0	0	1	0	0	1	1	0	0	1	0	0	D	3	2	1
28	Input5	1	0	1	1	0	1	1	0	0	1	1	0	0	1	0	0	D	3	3	1
29	On/Off	1	0	1	1	0	0	1	1	0	1	0	0	0	1	0	0	D	1	6	1
30	Shutter Op	1	0	1	1	0	0	1	0	0	1	0	0	1	1	0	0	D	9	2	1
31	Shutter Cl	1	0	1	1	0	1	1	0	0	1	0	0	1	1	0	0	D	9	3	1
32	HDMI	1	0	1	1	0	1	0	0	0	1	0	0	1	1	0	0	D	9	1	1