

EIKI:LC-WB42N/WB42NA IR Command List

- Transmission format of LCD projector operation key
: NEC Format (single command / command pipelining mode)
- Transmission format of PC mouse operation button (mouse cursor button) / L / R key
: Interlink Mouse Code Format (Includes 3 bit of ID)
- Format for the transmission of OSD Laser operation button (mouse cursor button)
: Interlink OSD Mouse Code Format (Includes 3 bit of ID)
- Custom Code + Custom Code
: 8 patterns as below
33h+00h(Default; code1), 33h+11h(code2), 33h+22h(code3), 33h+33h(code4),
33h+44h(code5), 33h+55h(code6), 33h+66h(code7), 33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	*1	L-CLICK Back-side Click Trigger Key
2	37	HDMI
3	00	ON-OFF
4	38	COMPUTER
5	05	VIDEO
6	08	NETWORK
7	16	INFORMATION
8	5B	KEystone
9	17	AUTO SET / CANCEL
10	8C	CURSOR UP
11	1E	CURSOR LEFT/VOLUME -
12	1D	CURSOR RIGHT/VOLUME +
13	8D	CURSOR DOWN
14	1C	MENU
15	0F	SELECT
16	*1	R-CLICK
17	43	FREEZE
18	84/85 *2	LASER
19	8B	NO SHOW
20	59	PAGE +
21	01	D.ZOOM +
22	8A	P-TIMER
23	5A	PAGE -
24	02	D.ZOOM -
25	0B	MUTE
26	18	LAMP CONTROL
27	82	SCREEN
28	0C	IMAGE
29	07	PIP
OB1	*1	MOUSE CURSOR BUTTON

*1... Transmit code for Mouse *2... Transmit code to set Laser Pointer / OSD Laser to ON/OFF