

EIKI LC-X800 IR Command List

- Transmission format of LCD projector operation key
: NEC Format (single command / command pipelining mode)
- Custom Code + Custom Code
: 8 patterns as below
33h+00h(Default; code1),33h+11h(code2),33h+22h(code3),33h+33h(code4),
33h+44h(code5),33h+55h(code6),33h+66h(code7),33h+77h(code8)

Key No.	Data Code (HEX)	Function
1	--	LIGHT
2	00	ON-OFF
3	1C	MENU
4	89	AUTO PC
5	8B	SHUTTER
6	8C	CURSOR UP
7	1E	CURSOR LEFT
8	0F	SELECT
9	1D	CURSOR RIGHT
10	8D	CURSOR DOWN
11	40	LENS SHIFT
12	82	SCREEN
13	0C	IMAGE ADJUST
14	47	ZOOM +
15	4A	FOCUS +
16	38	INPUT 1
17	46	ZOOM -
18	4B	FOCUS -
19	39	INPUT 2
20	43	FREEZE
21	88	D. ZOOM
22	06	INPUT 3
23	8A	P-TIMER
24	5B	KEYSTONE
25	08	INPUT 4
26	1A	FILTER
27	0D	IMAGE SELECT
28	16	INFORMATION