



EIKI



Quick start



Contents



Power Cord



Allen key



Power adapter



Remote control



Screw


*Differences according to regions. Display design and accessories may differ from those illustrated above.

32"




1 Unboxing

32"




The pictures are for reference only, and the actual product shall prevail

② Input/Output Terminals





3 Installation

32"




1. After opening the outer packaging, take out the instruction manual and other accessories, and carefully read the instruction manual

2. Remove the inner packaging cover and take out the monitor, which can be temporarily placed on the outer packaging cover




3. Remove the base

4. Open the wrench cover and take out three wrenches





4 Installation

32"




5. Take out the upright pole, which is now in a folded state

6. Unfold the upright pole, so that the upright pole is in the state shown in the right figure




7. Use a small wrench to tighten the internal screws clockwise, and note that both screws need to be tightened here



8. Insert the pole into the chassis, paying attention to aligning the charging port on the pole with the outer edge of the chassis. And tighten with a large wrench



5 Installation





9. Open the turntable cover clockwise



10. Place the display screen in the inner packaging to secure its position

11. Place the turntable into the display installation position and tighten the screws with a medium wrench, then install and tighten the turntable cover



12. Put all the wrenches back into the wrench box on the chassis Middle, and cover the wrench cover
Child, installation is complete, place the product in the correct position